


### **Motor Database**


#### Introduction

This section of the manual will take the user through an overview of the Motor Database Module. This module stores information on motors that you have wound in your shop. You can track these items by motor number, item number, serial number, model number or description. The Motor Database has predefined fields for the motor winding data.




In this section we will review the following in the Motor Database Module:

- Motor Database Entry
  - o Header
  - Insulation Specs
  - Coil Wind Data
- Motor Database Print
- Motor Database Inquiry
  - Header
  - Insulation Specs
  - Coil wind Data



### **Motor Database Entry**

The Motor Database Entry screen has a criteria selection as seen below. The information can be entered and maintained at any time.



#### **Motor Database Entry Field Options:**

**Motor Number:** Enter a valid fifteen character alphanumeric Motor Number and click the "OK" button or hit the "Enter" key to either enter a new motor number. All motor numbers are case sensitive. If using alpha characters, we recommend upper case letters.

Click on the magnifying glass, enter "F3", or right click for quick selection look-up to view a list of existing motor numbers.

Click on the "Cancel" button, enter "F4", click on the upper right corner "X" box, or the menu bar button with an arrow pointing through the open door to exit the application.


If you are entering a NEW motor number you will see the following:



Click "YES" to proceed with entering a new motor number or click "NO" or "Cancel" to return to the motor number field.

If you are entering an existing motor number the motor information will automatically be displayed.

**Header** – A detailed display of motor specifications provides nameplate data, slot count and diameter, number of leads, wire size and quantity plus much more.



### **OK/Cancel/Delete / Print**

**OK** – Accept data, clear screen, and return to the code entry field.


Cancel – Do not accept what has been entered, clear screen, and return to the code entry field.

**Delete** – Delete the entry from the file.

**Print** – Prints the motor information.

Additional screens provide both insulation specifications and coil winding data.

#### **Insulation Specs**



### **OK/Cancel/Delete / Print**


**OK** – Accept data, clear screen, and return to the code entry field.

**Cancel – Do not accept** what has been entered, clear screen, and return to the code entry field.

**Delete** – Delete the entry from the file.

**Print** – Prints the motor information.

#### **Coil Wind Data**



### **OK/Cancel/Delete / Print**


**OK** – Accept data, clear screen, and return to the code entry field.

**Cancel – Do not accept** what has been entered, clear screen, and return to the code entry field.

**Delete** – Delete the entry from the file.

**Print** – Prints the motor information.


#### **Motor Database Print**



**Beginning and Ending Motor Number:** Allows you to print database information for a specific motor number or a range of motor numbers.


**OK** – Accept data, and print the report.


Cancel – Do not accept what has been entered, clear screen, and return to the menu.



### **Motor Database Inquiry**

You have access to data that has been previously entered for the motor. This information can be quickly accessed through ACS SpeedSearch under Service Repair by clicking on the binoculars on the ACS tool bar or by selecting "F5".






**Motor Number:** Enter a valid fifteen character alphanumeric Motor Number and click the "OK" button. All motor numbers are case sensitive. If using alpha characters, we recommend upper case letters.

Click on the magnifying glass, enter "F3", or right click for quick selection lookup to view a list of existing motor numbers.

Click on the "Cancel" button, enter "F4", click on the upper right corner "X" box, or the menu bar button with an arrow pointing through the open door to exit the application.


#### Header

The system will display the Motor Header information.




The data displayed may not be edited in this inquiry option.

**Insulation Specs:** Displays insulation specs data entered in Motor Database Entry.



The data displayed may not be edited in this inquiry option.

**Coil Wind Data:** Displays the coil wind data entered in Motor Database Entry.



The data displayed may not be edited in this inquiry option.